




Back leather x1
A01





A06 install orienting line






































Note: For the left side, cut from front side of the leather






Shoulder belt and handle ear (hanger) x4
A05(Riveted with A03 and A04)
Note: Please adjust the length as your wish

NOTE: For the left side, cut from front side of the leather
For the right side, cut from the flesh side of the leather










Back pocket
A06(joint A01)





Lobster Clip leather x4
A09(joint A01 and A02)
Note: Adjust the length as your wish



xct x1
)

