



Print & Check

1. No matter what software you use to print, set your print scaling size to “100%” or “none scale” or “actual size”
2. After printing the layout, use your ruler to measure whether the 10cm or 5in line segment in the figure matches.

Print size confirmation



ZT Leather

ztleather.co
facebook.com/groups/ztleather
youtube.com/@ztleather

Tools & Materials

Leather Suggest

Thickness: 1.6mm

Type: Vegetable Tanned

Tools

Penknife

Cutting Knife

Utility Knife

Cutting Mat

Hammer

Leather Holes Punch(1mm, 4.5mm)

Needle and Thread

Sandpaper

Leather Burnisher

Adhesive Eraser


3M Spray Mount

Treatment Agent

Leather Finish

Hardware Parts

Double Cap “6x8” mm



Keychain diameter:

Inner is 22mm, outer is 28mm

